



2 STAGE HEAT PUMP WITH ROCK, EARTH, LAKE OR GROUND WATER AS HEAT SOURCE.

- Less than 3 kg refrigerant per cooling section/installation. This means no inspection requirement.
- The two scroll compressors can supply up to 65°C to the heating system.
- Double compressors give better power control, longer operating intervals, less wear and greater operational security.
- Display unit with easy-to-read colour screen.
- – See status and make settings via SMS with the SMS 40 accessory.
– Control the heat pump externally, with for example BMS, via the accessory MODBUS 40.
- The heat pump is available in the following sizes: 24, 30, 40 and 60 kW.
- Up to 540 kW with 9 x F1345 in the same system.
- Soft start relays and load monitor factory installed.
- Internally installed low energy circulation pumps (not brine pump for 40 or 60 kW).
- Prepared for pool heating with POOL 40 accessory.
- Prepared for control of up to four heating systems with ECS40/ECS41 accessory.
- Coefficient Of Performance (COP) up to 4.51 at 0/35 C according to EN 14511.
- Separate cooling modules for compressors and brine pumps give reliable service and lower noise levels.
- Easy to remove the cooling modules.

NIBE F1345

NIBE™ F1345 is a heat pump for heating large buildings, such as apartment buildings, churches and industrial premises. F1345 is a flexible product with advanced control equipment and can be adapted to several system solutions. The ground, bedrock or lakes can be used as the heat source. Groundwater can also be used as a heat source, but this requires an intermediate heat exchanger. Another area of use could also be ventilation recovery in multi-occupancy buildings. F1345 can control up to four different climate systems (requires accessory), for example a lower flow temperature in the underfloor heating loops than in the radiators. F1345 is also prepared for control of an external additional heater. At hot water production this can be prioritised, selectable with one or more compressors. This permits simultaneous production of heat and hot water.

INSTALLATION METHOD

The term “ground source” covers four different heat sources: rock, surface soil, ground water and lake.

Rock - using a ground probe

Ideal for refurbishment or adaptation from a fossil fuel heating system.

In the lower subsoil of the so-called “near-surface geothermal layer” lies a heat source with an almost constant temperature that can be utilised all year round. The heat pump collects stored solar energy from a collector in a hole drilled into the rock. The depth of the hole can vary between 90 – 200 metres, depending on the size of heat pump selected. This type of system can be used for all possible building types, large or small, public or private. It requires little space and the ground probe can be drilled in the smallest of gardens.



Surface soil - using a surface collector

Cost-effective energy collection.


During the summer, solar heat is stored in the soil. This is either directly absorbed as insulation or as heat from rain and the air from the near-surface layer of the soil. The heat pump collects this stored solar energy from a buried collector. That is, a hose filled with anti-freeze, and buried at a depth of about 80 – 100 cm, the length of the hose varies between 250 and 400 metres, depending on the size of heat pump selected. Using this energy for heating is a cost effective method. The highest yield can be obtained from soil with a high water content.



Ground water

A viable energy source for any building where ground water is easily accessible.


Ground water can also be utilised as a heat source since it has a temperature of between 4 and 12°C all-year round. The heat pump collects stored solar energy from the ground water. Normally, there is one well for drawing up water and one for returning it.



Lake collector

Cost-effective installation for lakeside homes.

If your home is built beside a water source such as a lake, heat from the lake water can be extracted using a surface soil collector anchored to the bottom of the lake.





HOW DOES F1345 WORK?

Principle of operation

F1345 consists of two heat pump modules (cooling module), circulation pumps and control system with possibility of additional heat. F1345 is connected to the brine and heating medium circuits.

In the heat pump evaporator, the brine (water mixed with anti-freeze, glycol or ethanol) releases its energy to the refrigerant, which is vaporised in order to be compressed in the compressor. The refrigerant, of which the temperature has now been raised, is passed to the condenser where it gives off its energy to the heating medium circuit and, if necessary, to any docked water heater. If there is a greater need for heating/hot water than the compressors can provide it is possible to connect an external immersion heater.

F1345 is extremely efficient thanks to a highly effective compressor in well dimensioned refrigerant circuits. Internally installed low energy circulation pumps and flex hoses (not brine pump for 40 or 60 kW). The brine respectively heating medium circuits are connected from the rear of the heat pump. Particle filter supplied. The heat pump can be connected to an optional low temperature distribution system. e.g. radiators, convectors or under floor heating. F1345 is equipped with a control computer for optimum and reliable operation. A large backlit TFT display shows information about status, operating time and all temperatures in the heat pump as well as certain information about any slave heat pumps, in colour using icons and text. F1345 is constructed on a robust frame with durable panels and effective soundproofing for the best possible comfort. All panels are easy to remove for easy access when installing and for servicing.



* The brine pump (1 x) for 40 or 60 kW is supplied and installed externally outside the heat pump.



GOOD TO KNOW ABOUT NIBE™ F1345

Transport and storage


F1345 should be transported and stored vertically in a dry place. When being moved into a building, F1345 may be leant back 45 °. NOTE! The heat pump is top heavy.

If the cooling modules are pulled out and transported upright, F1345 can be transported on its back.

The side panels can be removed for easier installation in the building.




NOTE! Ensure that the heat pump cannot fall over during transport.



Drawing out the cooling module

To simplify transport and service, the heat pump can be separated by pulling the cooling module out from the cabinet.

See the installer manual for comprehensive instructions about the separation.




Assembly

- Position F1345 on a firm base that can take the weight, preferably on a concrete floor or foundation. Use the heat pump's adjustable feet to obtain a stable set-up.
- Install with its back to an outside wall, ideally in a room where noise does not matter, in order to eliminate noise problems. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem.
- Wherever the unit is located, walls to sound sensitive rooms should be fitted with sound insulation.
- Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.

Installation area


Leave a space of 800 mm in front of the heat pump. Approximately 50 mm free space is required on each side in order to open the side hatches. The hatches do not need to be opened during service, all service on F1345 can be carried out from the front. There must be at least 300mm of free space above the heat pump. Leave space between the heat pump and wall behind (and any routing of supply cables and pipes) to reduce the risk of reproduction of any vibration.



* A normal installation needs 300 - 400 mm (any side) for connection equipment, i.e. level vessel, valves and electrical equipment.


GOOD TO KNOW ABOUT NIBE™ F1345

Dimensions



GOOD TO KNOW ABOUT NIBE™ F1345

Equipment



GOOD TO KNOW ABOUT NIBE™ F1345

Pipe connections

XL1	Connection, heating medium flow
XL2	Connection, heating medium return
XL6	Connection, brine in
XL7	Connection, brine out

HVAC components

EP14	Cooling module
EP15	Cooling module
GP1	Circulation pump
GP2	Brine pump
QM1	Drainage, climate system
QM2	Draining, brine side

Cooling components

EP1	Evaporator
EP2	Condenser
GQ10	Compressor

Sensors etc.

BT1	Temperature sensor, outdoor
BT10	Temperature sensor, brine in
BT11	Temperature sensor, brine out
BT12	Temperature sensor, condenser supply line

Electrical components

AA2	Base card
AA3	Input circuit board
AA4	Display unit
AA7	Extra relay circuit board
AA10	Soft-start card
AA26	Base card 2
AA100	Joint card
FC1	Miniature circuit-breaker
FB1	Motor cut-out
SF1	Switch

X1	Terminal block, incoming electrical supply
X2	Terminal block, non-return valve, external brine pump (only 40 and 60 kW) and external operating voltage (at tariff control)
X3	Terminal block, step controlled additional heat
X4	Terminal block, emergency mode relay
X5	Terminal block, buzzer alarm
X6	Terminal block, communication, sensors and software controlled inputs
X7	Terminal block, control signal external brine pump (only 40 and 60 kW)

Miscellaneous

PF1	Rating plate
PF2	Type plate, cooling section
PF3	Serial number plate
UB1	Cable gland, incoming electricity
UB2	Cable gland, power
UB3	Cable gland, signal


Designations in component locations according to standard IEC 81346-1 and 81346-2.

GOOD TO KNOW ABOUT NIBE™ F1345

Pump capacity diagram Heating medium side


24 kW

External available pressure, kPa




30 kW



External available pressure, kPa



Electrical output per circulation pump, W



Electrical output per circulation pump, W




The pump is adjustable, the flow can be adjusted in menu 5.1.11.

GOOD TO KNOW ABOUT NIBE™ F1345


40 kW

External available pressure, kPa




60 kW



External available pressure, kPa



Electrical output per circulation pump, W



Electrical output per circulation pump, W




The pump is adjustable, the flow can be adjusted in menu 5.1.11.

GOOD TO KNOW ABOUT NIBE™ F1345

Pump capacity diagram Brine side


24 kW

External available pressure, kPa




30 kW



External available pressure, kPa



Electrical output per circulation pump, W



Electrical output per circulation pump, W




The pump is adjustable, the flow can be adjusted in menu 5.1.9.

GOOD TO KNOW ABOUT NIBE™ F1345


40 kW

External available pressure, kPa




60 kW



External available pressure, kPa



Electrical output per circulation pump, W



Electrical output per circulation pump, W



The pump is adjustable, the flow can be adjusted using the speed switch on the pump.

THE DISPLAY

A large, easy to read multicoulour display gives everyone the chance to maximize the energy saving potential of this exciting green technology!

Display unit

Display, A

Instructions, settings and operational information are shown on the display. The easy-to-read display and menu system, facilitates navigation between the different menus and options to set the comfort or obtain the information you require.

Status lamp, B

The status lamp indicates the status of the heat pump. It:

- lights green during normal operation.
- lights yellow in emergency mode.
- lights red in the event of a deployed alarm.

OK button, C

The OK button is used to:

- confirm selections of sub menus/options/set values/page in the start guide.

Back button, D

The back button is used to:

- go back to the previous menu.
- change a setting that has not been confirmed.

Control knob, E


The control knob can be turned to the right or left. You can:

- scroll in menus and between options.
- increase and decrease the values.
- change page in multiple page instructions (for example help text and service info).

Switch, F

The switch assumes three positions:

- On (I)
- Standby (⏻)
- Emergency mode (⚠)



THE DISPLAY

Menu system

When the door to the heat pump is opened, the menu system's four main menus are shown in the display as well as certain basic information.

Menu 1 – Indoor climate

Setting and scheduling the indoor climate.

Menu 2 – Hot water

Setting and scheduling hot water production.

This menu only appears if a water heater is docked to the heat pump.

Menu 3 - Info

Display of temperature and other operating information and access to the alarm log.

Menu 4 – Heat pump

Setting time, date, language, display, operating mode etc.



Menu 5 - Service

Advanced settings. These settings are not available to the user. The menu is visible by pressing the back button for 7 seconds.

Start guide

The first time the heat pump is switched on a start guide is started. The start guide instructions state what needs to be carried out at the first start together with a run through of the heat pump's basic settings.

The start guide ensures that the start-up is carried out correctly and cannot be bypassed. The start guide can be started later in menu 5.7.



INSTALLATION

Pipe installation

Pipe installation must be carried out in accordance with current norms and directives. F1345 can operate with a return temperature of up to 58 °C and an outgoing temperature from the heat pump of 65 °C.

F1345 is not equipped with shut off valves; these must be installed outside the heat pump to facilitate any future servicing.

Pipe connection (cooling medium)

The pipe connections are on the rear of the heat pump.


Insulate all indoor brine pipes against condensation.

Mark the brine system with the antifreeze that is used.

Install the supplied safety valve at the expansion vessel as illustrated in the outline diagram. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost-free.

Install shut off valves as close to the heat pump as possible so that the flow to individual cooling modules can be shut off. Extra safety valves between the particle filter and shut off valves (according the outline diagram) are required.

Fit the supplied particle filter on the incoming brine pipe. Fit the supplied non-return valves on the outgoing pipe. In the case of connection to an open groundwater system, an intermediate frost-protected circuit must be provided, because of the risk of dirt and freezing in the evaporator. This requires an extra heat exchanger.



Note! Note that condensation may drip from the level vessel. Position the vessel so that this does not harm other equipment.

Pressure expansion vessel

The brine circuit must be supplied with a pressure expansion vessel.

The brine side must be pressurised to at least 0.05 MPa (0.5 bar).


The pressure expansion vessel should be dimensioned as set out in the following diagram, to prevent operating disturbances. The diagrams cover the temperature range from -10 °C to + 20 °C at a pre-pressure of 0.05 MPa (0.5 bar) and the safety valve's opening pressure of 0.3 MPa (3.0 bar).

Ethanol 28% (volume percent)

In installations with ethanol (28% volume percent) as the brine, the pressure expansion vessel must be dimensioned according to the following diagram.


Ethylene glycol 40% (volume percent)

In installations with ethylene glycol (40% volume percent) as the brine the pressure expansion vessel must be dimensioned according to the following diagram.



Ethylene glycol 40% (volume percent)


In installations with ethylene glycol (40% volume percent) as the brine the pressure expansion vessel must be dimensioned according to the following diagram.



INSTALLATION

Connection of external brine pump (only 40 and 60 kW)

Install the brine pump (GP16) according to the circulation pump manual for connection of incoming brine (EP14-XL6) and (EP15-XL6) between the heat pump and shut off valve (see image).



Pipe connection (water heater)

- Any docked hot water heater must be fitted with necessary set of valves.
- The mixing valve must be installed if the setting is changed so that the temperature can exceed 60 °C.
- The setting for hot water is made in menu 5.1.1.
- The safety valve must have a maximum opening pressure in accordance with the water heater manual and be installed on the incoming domestic water line. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost-free.



CAUTION! The heat pump/system is designed so that hot water production can occur with one or several cooling modules. This however entails different pipe or electrical installations.

Fixed condensing

If F1345 is to work towards the water heater with fixed condensing you must connect an external flow sensor (BT25) according to the description in the installer handbook. In addition, menu settings must be made (see installer handbook).

Pipe connection (heating medium)

Connecting the climate system

A climate system is a system that regulates indoor comfort with the help of the control system in F1345 and for example radiators, underfloor heating/cooling, fan convectors etc.

The pipe connections are on the rear of the heat pump.

Install the necessary safety equipment and shut off valves (installed as close to the heat pump as possible so that the flow to individual cooling modules can be shut off).

Fit the supplied particle filter on the incoming pipe.

The safety valve must have a maximum 0.6 MPa (6.0 bar) opening pressure and be installed on the heating medium return. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost-free.

When connecting to a system with thermostats on all radiators, a relief valve must be fitted, or some of the thermostats must be removed to ensure sufficient flow.

Fit the supplied non-return valves on the outgoing pipe.

Install the vent valves in the climate system if necessary.



CAUTION! When necessary you should install venting valves in the climate system.



CAUTION! The heat pump is designed so that heating production can occur with one or two cooling modules. This however entails different pipe or electrical installations.

INSTALLATION


NIBE F1345 can be connected in several different ways, some of which are shown below. Further option information is available in the respective assembly instructions for the accessories used.

F1345 docked with electric additional heat and water heater (floating condensing)

The heat pump (EB100) prioritises charging of hot water with half the power (cooling module EP14) via a reversing valve (QN10). When the water heater/accumulator tank (CP10) are fully charged (EB100-QN10) switches to the heating circuit. When there is a demand for heat, cooling module (EP15) starts first. For greater demands, cooling module (EP14) also starts for heating operation.

Additional heat (EB1) is connected automatically when the energy requirement exceeds the heat pump capacity.

If the water heater/accumulator tank (CP10) is fitted with an immersion heater (EB2) and a junction box (XD1) and the accessory card AXC 50 (AA5), the functions "temporary lux" and "periodic increase" can be used. A by-pass contactor is recommended.




INSTALLATION

2x F1345 docked with oil addition, pool and water heater (floating condensing)

The heat pump (EB100) prioritises charging of hot water with half the power (cooling module EP14) via a reversing valve (EB100-QN10). When the water heater/accumulator tank (CP10 and CP11) are fully charged (EB100-QN10) switches to the heating circuit. The other half of the output (cooling module EP15) prioritises pool heating via a reversing valve (CL11-QN19). When the pool is heated (CL11-QN19) switches to the heating circuit. When there is a demand for heat, cooling module (EP15) starts in heat pump (EB101) first. For greater demands, cooling module (EP14) also starts in (EB101) for heating operation.

Additional heat (EM1) is connected automatically when the energy requirement exceeds the heat pump capacity.

If the water heater/accumulator tank (CP10) is fitted with an immersion heater and a junction box the function "temporary lux" is used. A by-pass contactor is recommended.



INSTALLATION

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person and should be documented. The above applies to closed heating systems. If the heat pump is replaced, the installation must be inspected again.

Guideline values for collectors

Type	Surface ground heating, recommended collector length	Ground-source heating, recommended active drilling depth
24	3x350 – 3x400 m	2x180 – 3x180 m
30	3x450 – 4x450 m	3x150 – 5x150 m
40	4x500 – 6x500 m	4x170 – 5x200 m
60	6x450 – 8x450 m	6x150 – 8x180 m

For use with 40 x 2.4 PN 6.3 PEM hose.

This are rough example values. On installation the correct calculations must be made according to local conditions.

The length of the collector hose varies depending on the rock/soil conditions, climate zone and on the climate system (radiators or underfloor heating).

Max length per coil for the collector should not exceed 500 m.

The collectors must always be connected in parallel with the possibility of adjusting the flow for the relevant coil.

For surface soil heat, the hose should be buried at a depth of about 1 metre and the distance between the hoses should be at least 1 metre.

For several bore holes, the distance between the holes must be at least 15 m.

Ensure the collector hose rises constantly towards the heat pump to avoid air pockets. If this is not possible, air vents should be used.

As the temperature of the brine system can fall below 0 °C it must be protected against freezing down to -15 °C. One litre of ready mixed brine per meter of collector hose (applies when using PEM-hose 40 x 2.4 PN 6.3) is used as a guide value when making the volume calculation.

Control, general

The indoor temperature depends on several factors. Sunlight and heat emissions from people and household machines are normally sufficient to keep the house warm during the warmer parts of the year. When it gets colder outside, the climate system must be started. The colder it is outside, the warmer radiators and floor heating system must be.

The heat pump is controlled by built-in sensors for flow and return brine temperatures (collector). Brine return temperatures can, if so required, be limited to a minimum (e.g. for ground water systems).

Control of the heat production is performed based on the "floating condensing" principle, i.e. the temperature level needed for heating at a specific outdoor temperature is produced guided by collected values from the outdoor and flow sensors. The room temperature sensor can also be used to compensate the deviation in room temperature.

F1345 can be docked to an external unit with its own heating controls. In that case, the heat pump delivers heat up to a fixed temperature level. This is known as "Fixed condensing". The automatic heating control system is then controlled by the external unit's regulation device.



INSTALLATION

Basic functions

Heat production

F1345 is equipped with an outdoor temperature controlled heating control system. This means that the supply of heat to the house is regulated in accordance with the chosen setting of the regulating curve (curve slope and offset). After adjustment, the correct amount of heat for the outside temperature is supplied. The flow line temperature of the heat pump will hunt around the theoretically required value. For subnormal temperatures the control system calculates a heating deficit in the form of "degree-minutes" which means that heating production is accelerated. The larger the subnormal temperature, the greater the heat production.

Heat production can take place with one or several compressors.

Hot water production

This function requires accessory VST 20.

If the water heater is docked to F1345 when there is a demand for hot water, the heat pump gives this priority and devotes half its output to water heating. Heating is produced by the second compressor in this mode. Maximum time for hot water charging can be adjusted in the menu system. After this, heating is produced by both the compressors for the remaining period of time before further water heating can take place.

With two or more compressors connected for water heating this is engaged and disengaged automatically by the control system on demand. A reversing valve is required for each F1345 that is to charge hot water.

Hot water charging starts when the hot water sensor has fallen to the set start temperature. Hot water charging stops when the hot water temperature on the hot water sensor (BT6) has been reached.


For occasional higher demand for hot water, the temporary lux function can be used to raise the temperature for 3 – 12 hours (selected in the menu system).

Own curve

F1345 has pre-programmed non linear heating curves. It is also possible to create your own defined curve. This is an individual linear curve with one break point. You select a break point and the associated temperatures.

Under floor drying

F1345 has an integrated floor drying function. This allows for controlled drying of a concrete slab. It is possible to create your own program and to follow a pre-programmed time and temperature schedule.



Brine pump

The brine pumps (40 or 60 kW have 1 brine pump) normally follow the operation of the heat pump. There is a special operating mode for continuous operation for 10 days, followed by return to normal mode (this may be used before stable circulation has been established).

Alarm indications

The status lamp lights red in the event of an alarm and the display shows detailed information depending on the fault. An alarm log is created with each alarm containing a number of temperatures, times and the status of outputs.

Additional heat only

F1345 can be used exclusively with an additional heater to produce heat, for example before the collector installation is complete.

Room control

F1345 can be supplemented with a room sensor (BT50). The room temperature sensor has up to three functions:

1. Show current room temperature in the heat pump's display.
2. Option of changing the room temperature in °C.
3. Makes it possible to change/stabilise the room temperature.

Install the sensor in a neutral position where the set temperature is required. A suitable place is on a free inner wall in a hall approx. 1.5 m above the floor. It is important that the sensor is not obstructed from measuring the correct room temperature by being located, for example, in a recess, between shelves, behind a curtain, above or close to a heat source, in a draft from an external door or in direct sunlight. Closed radiator thermostats can also cause problems.

The heat pump operates without the sensor, but if one wishes to read off the accommodation's indoor temperature in F1345's display the sensor must be installed.

External control (AUX input)

F1345 can be controlled using signals from external systems (for example DUC) connected to three software controlled inputs (AUX inputs). The alarm and time conditions in F1345 override the external control.

The following functions can be controlled:

- Blocking of the compressors -EP14 and -EP15
- Blocking additional heat
- Blocking heating
- Tariff blocking
- Activation of temporary lux (extra hot water)
- External adjustment of flow temperature
- Forced control of brine pump(s)
- Activating fan speed (requires accessory NIBE FLM)

All control signals should occur with potential-free relays.

INSTALLATION

Step controlled additional heat

Heat pumps are not usually dimensioned to provide the entire heat output requirement, which is why additional output is necessary during cold days. The external step controlled additional heater (if connected) is automatically switched on (in different steps) if the output is not sufficient to reach the temperature levels requested by the control computer.

F1345 provides 230 V control signals for the additional heat, that is signals for controlling external relays, contactors etc, but not to supply them with power.

External step controlled additional heat can be controlled by up to three potential free relays in the heat pump (3 step linear or 7 step binary). With the AXC 50 accessory a further three potential free relays are used for addition control, which then gives max 3+3 linear or 7+7 binary steps.

Step in occurs with at least 1 minute interval and step outs with at least 3 seconds interval.

Master/Slave

Several heat pumps (F1345) can be interconnected by selecting one heat pump as master and the others as slaves.

The heat pump is always delivered as master and up to 8 slaves can be connected to it and supply up to 540 kW (with 9 x F1345 60 kW) in the same system. In systems with several heat pumps each pump must have a unique name, that is only one heat pump can be "Master" and only one can be for example "Slave 5".

External temperature sensors and control signals must only be connected to the master, except for external control of the compressor module and reversing valve(s) (QN10) that can be connected one to each heat pump.

Software controlled output (AUX output)

It is possible to have an external connection through the relay function via a potential free variable relay (max 2 A) on the X5 terminal block.

Optional functions for external connection:

- Indication of buzzer alarm (preselected at the factory).
- Controlling ground water pump.
- Cooling mode indication (only applies if accessories for cooling are present or if the heat pump has the integrated cooling function).
- Control of circulation pump for hot water circulation.
- External circulation pump (for heating medium).
- If any of the above is installed to terminal block X5 it must be selected in the control system.

The accessory card is required if two or more of the above functions are to be connected to terminal block X5 at the same time.


Load monitor

When many power consumers are connected in the property at the same time as the electric additional heat is operating, there is a risk of the property's main fuse tripping. The heat pump has integrated load monitors that control the electrical steps for the electrical additional heat by disconnecting step by step in event of overload in a phase. Reconnection occurs when other current consumption is reduced.

A current sensor should be installed on each incoming phase conductor in to the distribution box to measure the current. The distribution box is an appropriate installation point.

USB service outlet

F1345 is equipped with a USB socket in the display unit. This USB socket can be used to connect a USB memory stick to update the software, save logged information and handle the settings in F1345.



INSTALLATION

Extended functions

Pool

This function requires accessory POOL 40.

A reversing valve can be connected to control part, or all, of the heating medium flow to a pool exchanger. The reversing valve, or if so desired the reversing valves (although using the same control signal), is/are installed on the heating medium circuit which normally goes to a radiator system. You determine in the control system how many compressors are permitted to work with the pool. External circulation pump (GP10) must be installed for pool operation.

During pool heating the heating medium is circulated between the heat pump and the pool exchanger using the heat pump's internal circulation pumps.

The external circulation pump circulates the heating medium water in the climate system and the additional heat can be engaged as necessary at the same time as the external flow sensor continually meters the heating demand of the house.

Up to two different pool systems can be connected to F1345 and controlled individually, it does require two POOL 40-accessories.




Extra climate system

This function requires the ECS 40/ECS 41 or AXC 50 accessory if larger separate shunt valves are needed.


A shunt valve, flow and return sensor and a circulation pump are connected to a second heating circuit with a lower temperature demand (e.g. under floor heating system). The temperature in the extra climate system is controlled by the heat pump and the shunt valve by offsetting the heat curve (each climate system has its own heat curve), room sensor or room unit.

Up to 3 additional climate systems can be connected to the heat pump.




Hot water comfort

This function requires the accessory AXC 50 which gives the possibility of temporary lux, mixing valve and hot water circulation (an AXC 50 for each accessory function that is to be used).



Temporary lux (extra hot water)

This function requires the accessory AXC 50. If an immersion heater is installed in the tank it can be permitted to produce hot water at the same time as the heat pump prioritises heating.



Mixing valve

This function requires the accessory AXC 50. A temperature sensor reads the temperature of the outgoing water to the hot water taps and adjusts the mixing valve from the hot water heater until the set temperature (in the control system) has been reached.

Hot water circulation (VVC)

This function requires the accessory AXC 50. One pump can be controlled for the circulation of the hot water during selectable periods.

Cooling

The accessory AXC 50 may be needed for distribution of cooling to the climate system.

Passive cooling (4-pipe)

This function requires the accessory AXC 50 (an AXC 50 for each accessory function that is to be used).

The cooling system is connected to the heat pump collector circuit, through which cooling is supplied from the collector via the circulation pump and the shunt valve.



When cooling is required (activated from the outdoor sensor and any room sensor) the reversing valve and the circulation pump are activated. The shunt valve regulates so that the cooling sensor reaches the current set point value corresponding to the outdoor temperature and the set min. value for the cooling temperature (to prevent condensation).

Passive/active cooling (4-pipe)

This function requires reversing valve for cooling, circulation pump, shunt valve and accessory ACS 45.

This function makes both heat and cooling production independently of each other possible.


The cooling system supplies cooling from the collector circuit using a circulation pump via a shunt valve.

Passive cooling occurs without the compressor running, while active cooling occurs when the compressor is running.

For the installation to work the heating medium must flow freely, for example using UKV.

Operating mode cooling is activated by the temperature of the outdoor sensor and any room temperature sensors or room units.


When cooling is required the cooling reversing valve and the circulation pump are activated. The shunt regulates according to the cooling sensor and a cooling set point value that is determined by the selected cooling curve and offset. Degree minutes are calculated in response to the value on the brine out external temperature sensor and the cooling set point value. The degree minute value determines in which cooling mode the installation is according to the menu settings.



Passive cooling (2-pipe)

This function requires the accessory AXC 50 (an AXC 50 for each accessory function that is to be used).

The collector circuit is connected to a heat exchanger via a reversing valve. The other side of the exchanger is connected to the heating medium circuit via a shunt valve and a circulation pump.



When cooling is required (activated from the outdoor sensor and any room sensor or room unit) the reversing valve and the circulation pump are activated. The shunt valve regulates so that the cooling sensor reaches the current set point value corresponding to the outdoor temperature and the set min. value for the cooling temperature (to prevent condensation).

INSTALLATION

Passive/active cooling (2-pipe)

This function requires the accessory AXC 50 (an AXC 50 for each accessory function that is to be used).

The heating/cooling modes are controlled by 4 reversing valves, which, depending on the outdoor temperature and/or room temperature, switch between the different modes.

The supply of cooling to the building is controlled by the set curve slope and the offset of the curve in the control system. After adjustment the correct amount of cooling for the current outdoor temperature is supplied. The flow temperature from the reversing valves will hover around the theoretical required value (settable in the control system). For excess temperatures F1345 calculates a surplus in the form of degree minutes, this results in the acceleration of cooling production the greater the excess temperature.

F1345 automatically moves to cooling operation when the outdoor temperature exceeds the set value.

When the cooling requirement is large and passive cooling is not sufficient, active cooling is engaged at the set limit value. A compressor then starts and the resulting cooling circulates to the building's distribution system and the heat circulates out to the ground/rock collector. If several compressors are available these start with a difference of set degree minutes.

Groundwater pump

With the AXC 50 accessory (an AXC 50 for each accessory function that is to be used) a groundwater pump can be connected to the heat pump if the software controlled output (AUX output) is used for anything else.

This connection enables the use of ground water as heat source. The ground water is pumped up to an intermediate heat exchanger. An intermediate heat exchanger is used to protect the heat pump's exchanger from dirt and freezing. The water is released into a buried filtration unit or a drilled well.

The ground water pump runs at the same time as the brine pump.

Step controlled additional heat


With the AXC 50 accessory (an AXC 50 for each accessory function that is to be used) a further three potential free relays are used for addition control, which then gives max 3+3 linear or 7+7 binary steps.

Shunt controlled additional heat

Accessory AXC 50 (an AXC 50 for each accessory function that is to be used) can be used to connect shunt controlled addition to the heat pump.

This connection enables an external additional heater, e.g. an oil boiler, to aid with heating.

The heat pump controls a shunt valve and a circulation pump via AXC 50. If the heat pump does not manage to keep the correct flow temperature, the addition starts. When the boiler temperature has been increased to about 55°C, the heat pump sends a signal to the shunt valve to open from the addition. The shunt valve adjusts so the true flow



temperature corresponds with the control system's theoretical calculated set point value. When the heating requirement drops sufficiently so the additional heat is no longer required the shunt closes completely. However, the boiler will be kept warm for a further 12 hours to be prepared for any increase in the heating requirement.


Solar heating

With the Solar 42 accessory the F1345 together with:

VPAS can be connected to obtain solar heating for hot water charging and heating of buildings.

VPB can be connected to obtain hot water charging via heat exchanger.

The heat pump prioritises charging from the solar panel.



External circulation pump

With the AXC 50 accessory (an AXC 50 for each accessory function that is to be used) an external circulation pump (for the climate system) can be connected to the heat pump if the alarm relay (AUX output) is activated for another function.

The function is already included in the following accessory functions:

- Step controlled additional heat
- Shunt controlled additional heat
- Pool

MODBUS

The MODBUS 40 accessory enables F1345 to be controlled and monitored in a BMS system in the building. Communication occurs using MODBUS-RTU.



SMS control

The SMS 40 accessory enables F1345 to be controlled and monitored using a mobile phone via SMS messaging. For this to work, SMS 40 must be equipped with a valid GSM subscription.

There is no special GSM subscription requirement. A pay as you go card or a normal subscription work equally well. However a pay as you go card must be regularly topped up to ensure continued use sending SMS.

If the mobile telephone also has the Android operating system the "NIBE Mobile App" can be used. In the event of an alarm, SMS 40 can send an SMS to the programmed recipient and present it graphically.



Room unit

The RMU 40 accessory enables F1345 to be controlled and monitored from a different part of the building to where the heat pump is located.



INSTALLATION

Air collector

This function requires accessory NIBE AMB 30.

AMB 30 is a heat absorbent air module. The air module is most suitable when the ground-/rock collector does not have the capacity that the installation requires.



Outdoor air collector AMB 30 is connected to NIBE F1345 for only outdoor air operation or in combination with rock/ground collector (hybrid operation).

Outdoor air operation

During outdoor air operation the AMB 30 uses the outdoor air as a heat source and operation is permitted down to an outdoor air temperature of approx -7 °C. Outgoing brine from the F1345 is connected directly to the air module. When the outdoor air temperature is lower than the dimensioned balance temperature (the lowest temperature where the heat pump can manage all the heating) the additional heat must be accessible to supplement the heat pump.

Hybrid operation

When the outdoor air temperature is higher than 12 °C the control switches the reversing valves to operation with only AMB 30. When the outdoor air temperature is between approx. 0 and 10 °C the controls switches the reversing valve to operation with both AMB 30 and ground/rock collector (hybrid operation). At a set min. difference the control switches to operation with only ground/rock collector.



TECHNICAL SPECIFICATIONS



Type		24	30	40	60
Output data at nom flow according to EN 255 <small>Refers to performance of heat pump without circulation pumps</small>					
0/35					
Specified output	kW	23,2	31,3	40,0	57,8
Cooling output	kW	18,4	24,6	31,8	45,1
Electrical output	kW	4,84	6,67	8,17	12,7
COP _{EN 255}	-	4,79	4,69	4,89	4,55
0/50					
Specified output	kW	22,0	30,4	38,7	54,8
Cooling output	kW	15,6	21,6	28,0	38,4
Electrical output	kW	6,41	8,80	10,6	16,4
COP _{EN 255}	-	3,43	3,46	3,63	3,34
Output data according to EN 14511					
0/35					
Specified output (P _H)	kW	22,5	30,7	40,0	57,7
Electrical output (P _E)	kW	5,05	7,00	8,88	14,1
COP _{EN 14511}	-	4,42	4,36	4,51	4,10
0/45					
Specified output (P _H)	kW	21,5	30,1	39,0	55,1
Electrical output (P _E)	kW	6,08	8,47	10,6	16,5
COP _{EN 14511}		3,50	3,53	3,68	3,35
10/35					
Specified output (P _H)	kW	30,1	40,3	51,8	78,2
Electrical output (P _E)	kW	5,39	7,80	9,70	16,1
COP _{EN 14511}	-	5,54	5,15	5,32	4,84
10/45					
Specified output (P _H)	kW	28,7	39,5	50,9	72,7
Electrical output (P _E)	kW	6,44	9,25	11,7	18,4
COP _{EN 14511}		4,43	4,24	4,34	3,95
Electrical data					
Rated voltage		400V 3NAC 50 Hz			
Max operating current, heat pump ³⁾	A _{rms}	19,4	24,8	30,9	47,1
Max operating current, compressor	A _{rms}	7,8	10,5	13,9	19,9
Recommended fuse protection	A	25	30	35	50
Start current	A _{rms}	29	34	42	53
Max permitted impedance at connection point ¹⁾	ohm	-	-	-	0,4
Power, Brine circulation pump ³⁾	W	10 - 370	10 - 370	735 - 890	1150 - 1290
Power, Heating circulation pumps	W	5 - 174	5 - 174	5 - 174	5 - 174
IP class		IP 21			
Refrigerant circuit					
Type of refrigerant		R407C			R410A
Volume	kg	2 x 2.2	2 x 2.3	2 x 2.4	2 x 2.4
Cut-out value pressostat HP	bar	32			42
Difference pressostat HP	bar	-7			
Cut-out value pressostat LP	bar	0,8			2
Difference pressostat LP	bar	0,7			
Cut-out value, pressure transmitter LP (without AMB 30)	bar	1,3			3,5
Cut-out value, pressure transmitter LP (with AMB 30)	bar	0,8			2
Difference, pressure transmitter LP	bar	0,1			

TECHNICAL SPECIFICATIONS


Type		24	30	40	60
Brine circuit					
Max system pressure brine	bar	3			
Min flow	l/s	0,92	1,23	1,59	2,26
Nominal flow	l/s	1,18	1,62	2,09	2,90
Max external avail. press at nom flow ³⁾	kPa	92	75	92	72
Max/Min Incoming Brine temp	°C	see diagram			
Min. outgoing brine temp without/with AMB 30	°C	-12/-14			
Heating medium circuit					
Max system pressure heating medium	bar	4			
Min flow	l/s	0,37	0,50	0,64	0,92
Nominal flow	l/s	0,54	0,73	0,93	1,34
Max external avail. press at nom flow	kPa	78	72	70	50
Max/Min heating medium temp	°C	see diagram			
Sound power level (L _{WA}) <small>according to EN 12102 at 0-35</small>	dB(A)	47	47	47	47
Sound pressure level (L _{ON}) <small>calculated values according to EN ISO 11203 at 0/35 and 1m range</small>	dB(A)	32	32	32	32
Pipe connections					
Brine ext diam. CU pipe		G50 (2 " external)			
Heating medium ext diam., CU pipes		G50 (2 " external)			
Dimensions and weight					
Width	mm	600			
Depth	mm	620			
Height	mm	1800			
Required ceiling height ²⁾	mm	1950			
Weight complete heat pump	kg	325	335	352	353
Weight per cooling module	kg	130	135	143,5	144
Part no.		065 110	065 111	065 112	065 113

- 1) Max. permitted impedance in the mains connected point in accordance with EN 61000-3-11. Start currents can cause short voltage dips that could affect other equipment in unfavourable conditions. If the impedance in the mains connection point is higher than that stated it is possible that interference will occur. If the impedance in the mains connection point is higher than that stated check with the power supplier before purchasing the equipment.
- 2) With feet dismantled the height is approx. 1650 mm.
- 3) This technical data applies to the brine pump supplied for 40 and 60 kW.


Working range, compressor operation

The compressor provides a supply temperature up to 65 °C, the remainder (up to 70 °C) is obtained using the additional heat.

Water temperature



SUPPLIED COMPONENTS



Outdoor sensor




Current sensor
(Inner diameter
11.8mm), not 60 kW




Safety valve
(3 bar)



Aluminium tape



Insulation tape



Heating pipe paste



Temperature sensor
(5 x)




Non-return valves
(4x G2, internal thread)



O-rings



External brine pump
(for 40 and 60 kW
only)



Cable tie



Particle filter
24 - 40 kW: 2 pcs
G1 1/4 (internal
thread), 2 pcs G1 1/2
(internal thread)
60 kW: 2 pcs G1
1/4 (internal thread),
2 pcs G2 (internal
thread)




Installer manual



User manual


The enclosed kit is located on the packaging for
the heat pump.

ACCESSORIES




ACS 45
Active/Passive cooling (4-pipe)

Part no. 067 195




ELK
External electrical addition
These accessories may require
accessories card AXC 50.

ELK 213	Part no. 069 500
ELK 15	Part no. 069 022
ELK 26	Part no. 067 074
ELK 42	Part no. 067 075



ECS 40/ECS 41
Extra shunt group
This accessory is used when
F1345 is installed in houses with
two or more different climate
systems that require different
supply temperatures.
ECS 40 Part no. 067 061
(max 80 m²)
ECS 41 Part no. 067 099
(min 80 m²)



FLM
Exhaust air module
FLM is an exhaust air module
specially designed to combine
recovery of mechanical exhaust
air with an energy collector in
rock.

FLM	Part no. 067 011
Bracket pack	Part no. 067 083




HR 10
Auxiliary relay

Part no. 089 423



MODBUS 40
Communications module
MODBUS 40 enables F1345 to
be controlled and monitored in
a BMS system. Communication
occurs using MODBUS-RTU.

Part no. 067 144



SMS 40
Communications module
SMS 40 enables operation and
monitoring via a GSM module, us-
ing a mobile phone via SMS mes-
sages. If the mobile telephone has
the Android operating system the
"NIBE Mobile App" can be used.


Part no. 067 073



AMB 30
Air module, collector

Part no. 065 046

ACCESSORIES




POOL 40

Pool heating

POOL 40 is an accessory that enables pool heating with F1345. (max 17 kW)

Part no. 067 062



KB R32

Filling valve kit

Filling valve kit for filling brine in the collector hose for rock heat pumps. Includes dirt filter and insulation.

Part no. 089 971




RMU 40

Room unit

RMU 40 means that control and monitoring of the heat pump can be carried out in a different part of the accommodation to where F1345 is located.

Part no. 067 064




SOLAR 42

Solar pack

Solar 42 means that F1345 can be connected to solar heating.

Part no. 067 084



AXC 50

Accessory card

An accessory card is required if step controlled additional heat (e.g. external electric boiler) or if shunt controlled additional heat (e.g. wood/oil/gas/pellet boiler), passive/active cooling 2 pipe, passive cooling 2 respectively 4 pipes or if hot water comfort is to be connected to F1345.

Part no. 067 193



UKV

Neutralization vessel

UKV 200	Part no. 080 300
UKV 300	Part no. 080 301
UKV 500	Part no. 080 302



VPA

Hot water heater

VPA 300/200 CU	Part no. 088 710
VPA 300/200 E	Part no. 088 700
VPA 450/300 CU	Part no. 088 660
VPA 450/300 E	Part no. 088 670
VPAS 300/450 CU	Part no. 087 720
VPAS 300/450 E	Part no. 087 710




VPB

Hot water heater

Water heater with charge coil.

VPB 500	Part no. 083 220
VPB 750	Part no. 083 230
VPB 1000	Part no. 083 240




VST 20

Hot water control


Reversing valve, Cu-pipe Ø35 (Max recommended power, 40°kW)

Part no. 089 388



Immersion heater IU

3 kW	Part no. 695 20 30
6 kW	Part no. 695 20 71
9 kW	Part no. 695 20 97




K11

Connection box

Connection box with thermostat and overheating protection.

Part no. 018 893




HPAC 42

Active/Passive cooling (2-pipe)

HPAC combined with a heat pump is a climate control system for heating and cooling houses and apartment buildings. (Max 40 kW)

Part no. 067 025



NIBE is ISO-certified:
SS-EN ISO 9001:2000
SS-EN ISO 14001:2004

This brochure is a publication from NIBE. All product illustrations, facts and specifications are based on current information at the time of the publication's approval. NIBE makes reservations for any factual or printing errors in this brochure.
Photos: www.benfoto.se. ©NIBE 2012.



NIBE Energy Systems AB
Box 14
285 21 Markaryd
SWEDEN
Tel. +46 433 - 73 000
www.nibe.eu